



RED • DOT
ZERO

EDDC

EVOLVED DEFENSE CONCEPTS

WWW.EVOLVEDDEFENSECONCEPTS.COM


HOW TO ZERO

1. Measure 10yds (30ft) to target face
2. Adjust optic brightness to get the smallest, tightest dot for your lighting conditions
3. Adjust windage/elevation settings to get the dot as center in the optic window as possible
4. Aim pistol at the target putting the red dot in the middle of the center circle on the target (next page). Take 5 slow, controlled shots to get an average POI (Point Of Impact)
5. Count the number of squares (up/down & left right) that the average POI is away from dead-center of the target (each square on the target is equal to 5 clicks on a 1MOA optic, so 5 squares left of center = 25 clicks right & 3 squares below center = 15 clicks up)
6. Repeat steps 4 & 5 until satisfactorily zeroed

10YD PISTOL RED DOT ZERO

EEDCC

EVOLVED DEFENSE CONCEPTS



EEDCC

EVOLVED DEFENSE CONCEPTS

WWW.EVOLVEDDEFENSECONCEPTS.COM